

February 20, 2006

## PARTS LIST – KIT # 1003 THE SKIFF

### Laser-Cut Material:

*(1/16" basswood, except for sets D and E)*

#### Set A:

- 1 - Inner transom (S2)
- 1 - Transom seat (S4)
- 2 - Daggerboard case sides (S9)
- 1 - Daggerboard case back frame (S10)
- 1 - Daggerboard case front frame (S11)
- 2 - Daggerboard case trim (S12)
- 1 - Daggerboard (S13)
- 2 - Daggerboard grips (S14)
- 2 - Lower oarlock bases (S15)
- 2 - Upper oarlock bases (S16)
- 2 - Rudder cheeks (S18)
- 1 - Tiller (S20)
- 3 - Mast step (S22)

#### Set B:

- 1 - Hull bottom (S8)
- 6 - Oar blanks (S24)

#### Set C:

- 1 - Outer transom (S1)
- 1 - Transom knee (S3)
- 2 - Hull sides (S5)
- 1 - Midships seat (S6)
- 1 - Forward seat (S7)
- 1 - Rudder (S17)
- 2 - Gudgeons (S19)
- 1 - Keel (S21)
- 2 - Cleats (S23)

#### Set D:

- 1 - Sail (S25) (rip-stop nylon)

#### Set E:

- 1 - Base (S26) (1/4" basswood)

### Strip Wood:

- 4 - 1/16" x 3/16" x 14-1/2" (chines, gunwales) W1373
- 2 - 1/8" x 1/4" x 13" (inner chines) W1387
- 1 - 3/16" x 1/4" x 2" (stem, shaped) W1392
- 1 - 3/16" x 3/16" x 2" (stem trim) W1391

### Dowel:

- 3 - 1/16" x 3/8" (pintles, rudder pin) W1422
- 1 - 1/8" x 9" (sprit) W1261
- 1 - 1/4" x 12" (mast) W1263

### Fittings:

- 1 pair - oarlocks F0464

### Miscellaneous:

- 1 - 4' length of thread R1659
- 1 - bottle of white glue 31000
- 1 - two-sided sanding block 1003SB
- 1 - sheet of plans 1003P
- 1 - set of instructions 1003M
- 1 - Britannia note & guarantee BJNG
- 1 - Box W1553